Beam Z BWA418
Dimm
Shutter
Red
Green
Blue
White
Macro
Programms
Temp

SHOWTEC Compact Par 18 MKII
Master Dimmer
Red 0-100%
Green 0-100%
BLUE 0-100%
STROBE EFFECT
Programms

Double Head RGBW-50
Pan
Pan-16
Tilt
Tilt-16
XY-S
Tilt-360
Dimm
Shutter
Red-1
Green-1
Blue-1
White-1
Red-2
Green-2
Blue-2
White-2
Motor A
Speed
Auto
Speed-A
Reset

Martin MAC-500E
Shutter
Dim
Color1
Color2
Gobo1
Gobo_Pos
Gobo2
Focus
Iris
Effectwheeel
Pan
Pan-16
Tilt
Tilt-16
Posi-Speed
Intensitymspeed

Wash 40 LED
PAN grob
PAN fein
TILT grob
TILT fein
Slow - Fast
Dimming
Red 0-100%
Green 0-100%
BLUE 0-100%
WHITE 0-100%
COLOUR EFFECT
Programms
Reset

Halo 19-15
Strobe
Dim
Zoom
Pan
Pan-16
Tilt
Tilt-16
Reset
Colormix
ColorRed
ColorGreen
ColorBlue
ColorWhite
Color mix
dark time
dark => bright
bright => dark
bright time
Positionsspeed
Aura-Shutter
Aura-Dim
Aura-Colormix
Aura-Color Red
Aura-Color Green
Aura-Color Blue

CH	Function	DMX	Details
1	Pan	0-255	0 to 540 degree
2	Tilt	0-255	0 to 270 degree
3	Pan/Tilt Speed	0-255	From fast to slow
4	Dimmer	0-255	Linear dimmer from dark to bright
5	Strobe	0-3	Light off
		4-7	Light up
		8-76	Strobe with the same step from slow to fast
		77-145	Strobe with pulse from slow to fast
		146-215	Strobe with random from slow to fast
		216-255	Light up
6	CMY-C	0-255	From light to dark
7	CMY-M	0-255	From light to dark
8	CMY-Y	0-255	From light to dark
9	Color C	0-7	Open
		8-255	Color gradually change
10	Color M	0-7	Open
		8-255	Color gradually change
11	Color Y	0-7	Open
		8-255	Color gradually change
12	Rotating Gobo Wheel	0-8	Open
		9-17	Gobo 1
		18-26	Gobo 2
		27-35	Gobo 3
		36-44	Gobo 4
		45-53	Gobo 5
		54-63	Gobo 6
		64-73	Gobo 6 shake, from slow to fast
		74-82	Gobo 5 shake, from slow to fast
		83-91	Gobo 4 shake, from slow to fast
		92-100	Gobo 3 shake, from slow to fast
		101-109	Gobo 2 shake, from slow to fast
		110-118	Gobo 1 shake, from slow to fast
		119-127	Open
		128-189	Forward-directional rainbow effect, from slow to fast
		190-193	Stop
		194-255	Reversed-directional rainbow effect, from slow to fast
13	Gobo Rotation	0-63	Gobo rotation orientation
		64-145	Forward-directional rotation，from slow to fast
		146-149	Stop
		150-231	Reversed-directional rotation，from slow to fast
		232-255	Gobo rotation, Bi-directional rainbow effect
14	Fixed Gobo Wheel	0-7	Open
		8-15	Gobo 1
		16-23	Gobo 2
		24-31	Gobo 3
		32-39	Gobo 4
		40-47	Gobo 5
		48-55	Gobo 6
		56-63	Gobo 7
		64-71	Gobo 7 shake, from slow to fast
		72-79	Gobo 6 shake, from slow to fast
		80-87	Gobo 5 shake, from slow to fast
		88-95	Gobo 4 shake, from slow to fast
		96-103	Gobo 3 shake, from slow to fast
		104-111	Gobo 2 shake, from slow to fast
		112-119	Gobo 1 shake, from slow to fast
		120-127	Open
		128-190	Forward-directional rainbow effect, from slow to fast
		191-193	Stop
		194-255	Reversed-directional rainbow effect, from slow to fast

CH	Function	DMX	Details
15	Prism	0-15	No function
		16-255	Prism effect
16	Prism Rotation	0-15	No function
		31-159	Reversed-directional rotation，from slow to fast
		160-255	Forward-directional rotation，from slow to fast
17	Frost	0-255	From less to more
18	Focus	0-255	From far to near
19	Zoom	0-255	From far to near
20	IRIS	0-63	IRIS from big to small
		64-255	IRIS effect
21	Function Channels	0-7	No function
		8-15	No function
		16-23	No function
		24-31	No function
		32-39	No function
		40-47	No function
		48-55	No function
		56-87	No function
		88-95	No function
		96-111	XY reset
		112-119	Color reset
		120-127	Gobo reset
		128-135	Frost, Prism, IRIS reset
		136-143	Foucs, Zoom reset
		144-151	All reset
		152-159	No function
		160-167	No function
		168-175	No function
		176-255	No function